

HOROSYS

Company Profile

Based in Switzerland, HOROSYS is an integrator specialized in microtechnique, microassembly, desktop machine development, as well as precision and metrology instrumentation. HOROSYS assists in the development of projects from idea to the end product, with after-sales services provided.

Product Overview

Thanks to its oval base system, rotary end flange, and waterproof **sleeve cover**, the robot sleeve guarantees optimum protection of the Meca500 6-axis robot.

Product Description

Specially developed for the Meca500, the sleeve is made of coated polyamide fabric (Telupro®), is extremely resistant, lightweight, flexible and does not influence the accuracy of the robot. It's oval base allows for simple and fast fixing of the sleeve. It is equipped with fixing & positioning holes, it allows to repeatedly fix the entire robot with its protection system. It features a safe passage of the robot's power and communication cable, as well as compressed air passages. The sleeve allows you to use the Meca500 in environments with internal overpressure.

Contact

Christophe Taramarcz

cta@horosys.ch

info@horosys.ch

Tél: +41 32 968 16 16

Rue de la Croix-Fédérale 8

CH-2300 La Chaux-de-Fonds